

AirPex

Apex locator USER MANUAL

Changzhou Sifary Medical Technology Co.,Ltd.


c	_	n	٠,		n	÷
U	U	П	ц	7	ш	L

1. Scope	e of AirPex	4
1.1	Parts Identification	4
1.2	2 Components and Accessories	5
1.3		
2. Symb	ools used in the User Manual	6
3. Befor	e Use	8
3.1	I Intended Use	8
3.2	2 Contraindications	8
4. Instal	ling the AirPex	10
4.1	Connecting file clip, lip hook and extension cord	10
4.2	2 Connecting charge base	11
5. Use li	nterface	12
6. Opera	ation	13
6.1	I Charge	13
	2 Function checking of APEX locator	
6.3	3 Operation and not suitable condition	17
7. Maint	enance	26
8. Troub	oleshooting	29
9. Techr	nical Data	30
10. EMC	Tables	32
11. State	ement	40


## 1. Scope of AirPex

#### 1.1 Parts Identification

- 1. Charge Base
- 2. APEX Locator
- 3. Lip Hook
- 4. Touch Probe
- 5. File Clip
- 6. Extension Cord



## 1.2 Components and Accessories



## 1.3 Options (sold separately)

## 2. Symbols used in the User Manual

WARNING	If the instructions are not followed properly, operation may lead to hazards for the product or the user/patient.		
NOTE	Additional information, explanation of operation and performance.		
SN	Serial number		
REF	Catalogue number		
***	Manufacturer		
~	Date of manufacture		
LOT	Lot of manufacture		
	Safety class II device		
ⅉ	Type B applied part		
((	CE marking		
	Direct current		
Z Z	Do not dispose of with normal household waste		

Page 6/41

2 Symbols used in the User Manual

2 Symbols used in the Oser Haman			
Ť	Store in a dry place		
134°C	Can be autoclaved up to a maximum temperature of 134° Celsius		
EC REP	Authorized Representative in the European Community		
-20°C -55°C	Temperature limitation		
20%	Relative humidity		
70kPa 106kPa	Atmospheric pressure		
Eighteeth	Manufacturer's LOGO		
<b>⊗</b>	Refer to instruction manual/booklet		

#### 3. Refore Use

#### 3.1 Intended Use

AirPex is intended for measuring canal length.

This device must only be used in hospital environments, clinics or dental offices by qualified dental personnel and not used in the oxygen-rich environment.

#### 3.2 Contraindications

This device must not be used in cases where a patient has been fitted with an implanted heart pacemaker (or other electrical equipment) and has been cautioned against the use of small electrical appliances (such as electric shavers, hair dryers, etc.)

Safety and effectiveness have not been established in pregnant women and children.



#### WARNING

Read the following warnings before use:

- The device must not be placed in humid surroundings or anywhere where it can come into contact with any type of liquids.
- 2. Do not expose the device to direct or indirect heat sources. The device must be operated and stored in a safe environment.
- 3. The device requires special precautions with regard to electromagnetic

#### 3 Before Use.

compatibility (EMC) and must be installed and operated in strict compliance with the EMC information. In particular, do not use the device in the vicinity of fluorescent lamps, radio transmitters, remote controls and do not use this system near the active HF Surgical Equipment in the hospital. Portable RF communications equipment (including peripherals such as antenna cables and external antennas) should be used no closer than 30 cm (12 inches) to any part of the AirPex, including cables specified by the manufacturer. Otherwise, degradation of the performance of this equipment could result. Do not charge, operate or store at high temperatures. Comply with the specified operating and storage conditions.

- 4. Gloves and a rubber dam are compulsory during treatment.
- If irregularities occur in the device during treatment, switch it off. Contact the agency.
- 6. Never open or repair the device yourself, otherwise, void the warranty.

## 4.Installing the AirPex

#### 4.1 Connecting file clip, lip

#### hook and extension cord

Connect file clip, extension cord and lip hook to APEX locator as shown in the picture. Also, use both extension cords according to actual situation.




## NOTE

Please use the original file clip and lip hook that manufactured by Sifary. Because the size of the unoriginal file clip and lip hook are different, it may damage the APEX locator or cause deviation of measurement accuracy.

## 4.2 Connecting charge

#### base


Plug the USB of adapter into the charge base, and plug the other end into a power outlet.





Only the original adapter could be used.

Put the APEX locator in the groove in the middle of the charge base. The power LED on charge base will light up. And the interface of APEX locator will light up to show that is charging.






NOTE

Put the APEX locator on the charge base in the right direction, otherwise the APEX locator will not be charged.

#### 5 Use Interface



- Set kev S (1)
- Power kev 😃
- (3) Reference range
- (4) Apical area display
- (5) Reference point
- (6) Measuring bar
- (7) Measured value
- (8) Volume display
- (9) Power display

#### Turn Power On/Off

Press U to turn on. Long press U more than 2 seconds, or no operation for 3 minutes to turn off.

#### Volume control

During standby state, shot press U to cycle the volume through the minor to the maximum.

#### Setting the reference point

During standby state, press S to set the reference point between 0~1. Seven points can be selected circularly. The cursor flashing position indicates the selected reference point.

#### Power display

Display the remaining power through the number of grid.


#### Reference range

The flash of the measuring bar is the current measured vale, represents the estimated distance from the apical foramen in millimeters.

#### Display reversing

During standby state, press 😃 and 💲 together to reverse the display.

## 6.1 Charge



Charging indication appears on the screen, and flashes slowly, when battery is fully charged or in a state near full charge, the flash will stop. Fully charged will take about 4-5 hours, depending on residual battery power and battery state.


It can be recharged 300-500 times, depending on the operating conditions of the device.



#### WARNING

Do not change the battery, only trained technician or distributor can change the battery, the electronic parts will be damaged if use a wrong battery or install with a wrong way.

## 6.2 Function checking of APEX locator







- Confirm the device with short touch file clip and lip hook before.
- Confirm that the tester is not installed on the APEX locator Then connect the file clip, lip hook and extension cord according to chapter 5.1. Finally, touch the lip hook with exposed metal position on file clip, the measurement on the screen should be shown as -2.



## NOTE

If the measurement shown is not -2, check that the connection is normal If the normal connection still does not show the expected value, please stop using the device and contact the local dealer for processing.

## 6.3 Operation and not suitable condition

Press the back cover of the file clip to make the hook of the file clip stick out. And hook the metal handle of the root canal file. Release the pressure and use the elasticity of the file clip to complete the connection between the file clip and the root canal file.



## **♠** NOTE

- When connecting the root canal file, make sure that the file clip and the root canal file handle are basically perpendicular, otherwise the chuck of the file clip will be easily damaged.
- This equipment does not include the root canal file. We need to buy another suitable model according to the clinical needs. The metal part of the root canal file should be well conductive.



When the file clip can't enter the patient's mouth, the file clip can be replaced by the extension cord with the touch probe. Press the touch probe on the metal handle of the root canal file to complete the connection between the touch probe and the root canal file.



- Hook the lips to the patient's lips. Ensure contact with the lips fully. Then the root canal file is slowly inserted into the unblocked root canal.
- If the patient is fitted with a metal crown or other conductive devices, the root canal file clip and the metal part of the file clip should not be in contact with it, so as to avoid causing wrong measurement results.
- APEX locator should be fixed in patient's collar with the clip.

## $\Lambda$

### NOTE

- To prevent measurement errors caused by conduction between the gums or adjacent root canals, dry the pulp chamber floor with cotton balls or other means before testing.
- Using the correct number and taper of the canal file, make it fully contact with the canal wall. is conducive to accurate measurement.
- As the root canal file is inserted, the measurement bar on the screen lights up from top to bottom.
- When displayed as shown in figure 1, the

Fig.1



Fig.2



value of the reference range is 2, indicating that the distance from the tip of the tooth root is about 2mm at this time. At the same time, the APEX locator emits a "di" alarm sound at a long interval.

- When displayed as shown in figure 2, it means that the distance from the tip of the tooth root is close, about 1.5 mm, and the time interval of "di~di~" alarm sound emitted by the APEX locator becomes shorter.
- When displayed as shown in figure 3, it means that it reaches the tip of the tooth root. The measured value is 00, which is the actual length of the root canal to be measured.
- When displayed as shown in figure 4, it means that the root canal file has gone beyond the tip of the tooth, and the main body emits a very urgent "di~~" alarm sound.



## NOTE

The tip of the tooth root position (measured value: 00) measured by this device is the Major/Anatomic apical foramen. In clinical practice, in order to prevent surgical failure caused by piercing the root apical orifice, 0.5-

1.0 mm is usually taken from the measured value, which is the Minor/Physiological apical foramen prepared for root canal.

- The value of the reference distance is only an estimated value, not a clinical basis.
  - The measured value does not represent the distance, only the trend of gradual entry.



### WARNING

- During measuring, enter slowly to prevent piercing the tip of the root.
- The APEX locator is used to determine the working length of the root canal. In clinical use. it must be combined with X-ray and other means to determine the working length of the root canal
- The device should be used by dentists with knowledge of dental root canal length and skill in operation.

Fig.3



Fig.4



#### Unsuitable situation of root canals for Electric Measurement

Cannot obtain precise measurements if the root canal conditions as below



#### Root canal with a large apical foramen

The root canal cannot be accurately measured because of the lesion or incomplete development of the apical foramen. The results may show that the length measured is shorter than the actual one.




### Root canal blood overflow from the opening

If blood spills from the root opening and contacts the gums, it will cause leakage of electricity, which cannot be accurately measured. Wait for the bleeding to stop completely. Clean the root canal and the opening, completely empty the root canal blood, and then measure it.

# The root canal uses a chemical solution to flow out from the opening


If a chemical solution flows out of the root canal, it is impossible to get an accurate measurement.

It is important to remove the overflow from the opening.



#### Broken crown


If the crown is broken, a segment of the gingival tissue enters the lumen, and the contact between the gingival tissue and the root file causes electrical leakage, which cannot be accurately measured. In this case, the appropriate material should be used to isolate the gingival tissue.



# The crack tooth Leakage through branch of the root canal


Broken teeth can cause electrical leakage and cannot be accurately measured.

Branch tubes can also cause leakage.




# Retreatment canal which was filled with gutta-percha

The gutta-percha must be completely removed to eliminate its insulation, then pass a small file all the way through the apical foramen and then put a little saline in the canal, but do not let it overflow the canal opening.




## Crown or metal prosthesis that touches gingival tissue

Accurate measurement cannot be obtained if the file touches a mental prosthesis that is touching gingival tissue. In this case, widen the opening at the top of the crown so that the file will not touch the mental prosthesis before taking a measurement.



## Cutting debris on tooth Pulp inside canal


Remove all cutting debris on the tooth. Remove all the pulp inside the canal. Otherwise an accurate measurement



## Caries touching the gums


cannot be obtained

In this case, electrical leakage through the caries infected area to the gums are impossible to obtain an accurate measurement



#### Blocked canal

The meter will not run if the canal is blocked. Opening the canal all the way to the apical construction to measure it




## Extremely dry canal

If the canal is extremely dry, the meter may not work until it is quite close to the apex. In this case, try to moisten the canal with oxydol or saline.


# Difference measuring result between Apex locator reading and Radiography

Sometimes the reading of the apex locator reading does not correspond to the X-ray image. this does not mean inaccurate of apex locator or X-ray, depending on the angle of the X-ray beam, the root tip may not be displayed correctly. The position of the root tip seems to differ from its true position.



The X-ray photo shows that the actual apex of the root canal is not the same as the anatomic end. In fact, the apical foramen is located at the coronal end. in this case, X-ray may indicate that the file needle has not reached the apical foramen, even if it has actually reached the apical foramen.

#### 7. Maintenance





File clip and lip hook must be pre-cleaned and sterilized before every use.

**Pre-cleaning:** Use a soft brush or moist cloth to remove visible contaminations, then wipe all the surfaces with a cloth lightly moistened with Ethanol for disinfection (Ethanol 70 to 80vol%) at least 1 min, repeat for 5 times.

**Packing:** Pack each component in a separate steam-sterilization pouch.

#### 7 Maintenance

Sterilization: Steam sterilization at 134°C at least 6 minutes .

Minimum drying time after sterilization: 10 minutes.

**Storage:** Keep the components in sterilization packaging in a dry and clean environment.




## WARNING

Comply with your national guidelines, standards and requirements for cleaning, disinfection and sterilization.

Be careful to avoid cross contamination when performing maintenance.

Must be autoclaved after use for each.

## Disinfection components



Wipe all the surfaces with a cloth lightly moistened with Ethanol for Disinfection (Ethanol 70 to 80 vol%) at least 2min, repeat for 5 times.



Do not use anything except Ethanol for Disinfection (Ethanol 70 to 80 vol%).

Do not use too much ethanol as it's going into machine and damage the components inside.

## 8. Troubleshooting

When trouble is found, check the following points before contacting your distributor. If none of these are applicable or the trouble is not remedied even after action has been taken, the product may have failed. Contact your distributor.

Problem	Cause	Solution	
	The battery is flat.	Charge the battery.	
The power is not turned on.	Press the power switch too short time.	Long press the power switch.	
No charge	Put the APEX locator on the charge base in the wrong location.	Check the location.	
indicator flash on handpiece screen.	Charging is completed.	Checking the instructions of the battery.	
	The charge base is broken.	Contact your distributor.	
No sound.	Beep volume is set to 0.	Set beep volume to 1, 2 or 3.	

Page 29 / 41

## 9.Technical Data

Manufacturer	Changzhou Sifary Medical Technology Co.,Ltd
Model	AirPex
Dimensions	13cm x 11cm x 8cm±1cm (Outer box)
Weight	0.35kg±10%
Power supply	Lithium ion battery: 3.7V, 120mAh, ±10%
Charger power supply	AC 100-240 V, ±10%
Charger power output	5V 1A
Frequency	50/60Hz, ±10%
Power rating	<1W
Degree of protection	IPX 0
Electrical safety class	Class II

#### 9 Technical Data

Applied part	В
Operation mode	Continuous operation
Operating conditions	Use: in enclosed spaces Ambient temperature: 5°C ~ 40 °C Relative humidity: <80% Operating altitude < 3000m above sea level Atmospheric pressure: 70kPa-106kPa
Transport and storage conditions	Ambient temperature: -20 °C ~ +55 °C Relative humidity: 20% ~ 80 % Atmospheric pressure: 70kPa~106kPa

### 10.EMC Tables

# Guidance and manufacturer's declaration – electromagnetic emissions

The **AirPex** is intended for use in the electromagnetic environment specified below. The customer or the user of the **AirPex** should assure that it is used in such an environment.

Emissions test	Compliance	Electromagnetic environment - guidance		
RF emissions CISPR 11	Group 1	The <b>AirPex</b> uses RF energy only for its internal function. Therefore, its RF emissions are very low and are not likely to cause any interference in nearby electronic equipment.		
RF emissions CISPR 11	Class B	The <b>AirPex</b> is suitable for use in		
Harmonic emissions IEC61000-3-2	Class A	all establishments, including domestic establishments and those directly connected to the		
Voltage fluctuations/flicker emissions IEC 61000-3-3	Complies	public low-voltage power suppl network that supplies building used for domestic purposes.		

Page 32 / 41

# Guidance and manufacturer's declaration – electromagnetic immunity

The **AirPex** is intended for use in the electromagnetic environment specified below. The customer or the user of the **AirPex** should assure that it is used in such an environment.

Immunity test	IEC 60601	Compliance	Electromagnetic
	test level	level	environment - guidance
Electrostatic discharge (ESD) IEC 61000-4-2	+/- 8 kV contact +/- 2 kV, +/- 4 kV, +/- 8 kV, +/- 15 kV air	+/- 8 kV contact +/- 2 kV, +/- 4 kV, +/- 8 kV, +/- 15 kV air	Floors should be wood, concrete or ceramic tile. If floors are covered with synthetic material, the relative humidity should be at least 30 %.
Electrical fast transients/bursts IEC 61000-4-4	±2kV 100kHz repetition frequency	±2kV 100kHz repetition frequency	Mains power quality should be that of a typical commercial or hospital environment.
Surge IEC 61000-4-5	Line to line: ±0.5kV, ±1kV Line to earth: ±0.5kV, ±1kV, ±2kV	Line to line: ±0.5kV, ±1kV Line to earth: ±0.5kV, ±1kV, ±2kV	Mains power quality should be that of a typical commercial or hospital environment.

Page 33 / 41

10 EMC Tables

	10 EMC labi	Co .	
Voltage dips IEC 61000-4-11 Voltage interruptions IEC 61000-4-11	0% UT; 0.5 cycle at 0°, 45°, 90°, 135°, 180°, 225°, 270°, and 315°  0% UT; 1 cycle and 70% UT; 25/30 cycles sine phase at 0°  0% UT; 250/300 cycle	0% UT; 0.5 cycle at 0°, 45°, 90°, 135°, 180°, 225°, 270°, and 315°  0% UT; 1 cycle and 70% UT; 25/30 cycles sine phase at 0°  0% UT; 250/300 cycle	Mains power quality should be that of a typical commercial or hospital environment. If the user of devices require continued operation during power mains interruptions, it is recommended that devices be powered form an uninterruptible power supply or a battery
Rated Power frequency magnetic field IEC 61000-4-8	30 A/m 50Hz or 60Hz	30 A/m 50Hz or 60Hz	Power frequency magnetic field should be at levels characteristic of a typical location in a typical commercial or hospital environment.

Note: UT: rated voltage(s); E.g. 25/30 cycles means 25 cycles at 50Hz or 30 cycles at 60Hz

### Guidance and manufacturer's declaration - electromagnetic immunity

The **AirPex** is intended for use in the electromagnetic environment specified below. The customer or the user of the **AirPex** should assure that it is used in such an environment.

Immunity test	IEC 60601 test level	Compliance level	Electromagnetic environment - guidance
Conducted dis- turbances induced by RF fields IEC 61000-4-6	3 V 0.15 MHz – 80 MHz, 6 V in ISM bands be-tween 0.15 MHz and 80 MHz, 80 % AM at 1 kHz	3 V	Portable and mobile RF communications equipment should be usedno closer to any part of the AirPex, including cables, than the recommended separation distance calculated from the equation applicable to the frequency of the transmitter.
Radiated RF EM fields IEC 61000-4-3	3 V/m, 80 MHz – 2,7 GHz, 80 % AM at 1 kHz	3V/m	Recommended minimum separation distances See the RF wireless communication equipment table in "Recommended

#### 10 EMC Tables

Proximity fields from RF wireless communication equipment	See the RF wireless communicati on equipment	Complies	minimum separation distances"
equipment IEC 61000-4-3	equipment table in "Recommen ded minimum separation distances"		

#### Recommended minimum separation distances

Nowadays, many RF wireless equipments have being used in various healthcare locations where medical equipment and/or systems are used. When they are used in close proximity to medical equipment and/or systems, the medical equipment and/or systems' basic safety and essential performance may be affected. The **AirPex** has been tested with the immunity test level in the below table and meet the related requirements of IEC 60601-1-2:2014. The customer and/or user should help keep a minimum distance between RF wireless communications equipments and the **AirPex** as recommended below.

Test frequency (MHz)	Band (MHz)	Service	Modulation	Max power (W)	Distance (m)	Immunity test level (V/m)
385	380-	TETRA	Pulse	1.8	0.3	27

10 EMC Tables

390 400 modulation 18Hz  GMRS FM 430- 4400 ± 5 kHz deviation 460 1 kHz sine  710	10 EMC Tables						
450		390	400	modulation			
450				18Hz			
450							
## A # A # A # A # A # A # A # A # A #	450			-	2	0.3	28
710 745 745 704- 787 780 787 787 13, 17 810 810 870 880 8809 80090, TETRA 8800, 960 960 960 960 960 CDMA 850, LTE Band 5  1720 1845  1700- 1990 1990 1900; DECT; LTE Band 1,3,4, 25; UMTS  Pulse modulation 2 0.2 0.3 9  0.3 9  0.2 0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 28  0.3 0.3 0.3 0.3 0.3 0.3 0.3 0.3 0.3 0.	1.00	470	FRS	deviation	_	0.0	
745 704- Band 787 13, 17 217Hz 0.2 0.3 9  810 GSM Pulse modulation 2 0.2 0.3 9  800- 960 820, CDMA 850, LTE Band 5 120 GSM 1800; CDMA 1900; CDM				1 kHz sine			
745 704- Band 13, 17 217Hz 0.2 0.3 9  810 870 GSM 800/90, TETRA 800, Pulse modulation 2 0.3 28  930 For example of the state of the sta				Pulse			
780	745	-			0.2	0.3	9
17 810 870 870 870 870 870 870 870 870 870 87	780	787			V.2	0.5	ı
870  800/90, TETRA 800, Pulse modulation 2 0.3 28  930  930  930  930  950  960  820, CDMA 850, LTE Band 5  1720  1845  GSM 1800; CDMA 1900; CDMA 1900; GSM Pulse modulation 2 0.3 28  17700-1990  1990  1700-1990  1700-1990  1900; modulation 2 0.3 28  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1990  1700-1900  1700-1900  1700-1900  1700-1900  1700-1900  1700-1900  1700-1900  1700-1900  1700-1900  1700-1900  1700-1900  1700-1900  1700-1900  1700-1900  1700-1900  170	700		17	217112			
930   TETRA 800, Pulse modulation 2 0.3 28   930   960   820, CDMA 850, LTE Band 5   1720   GSM 1800; CDMA 1900; CDMA 1900; GSM Pulse 1970   1990   1900; modulation 2 0.3 28   1770   1970   1980   1980; modulation 2 0.3 28   1845   1770   1980   1980; modulation 2 0.3 28   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1845   1	810		GSM				
930 800- 960 820, CDMA 850, LTE Band 5  1720 1845  1700- 1970 1970 1970 1970 1970 1970 1970 1970	870				2	0.3	28
930   SOU- 960   SEU,							
930   iDEN   modulation   2   0.3   28			800,	Pulso			
930		800-	iDEN	modulation			
CDMA 850, LTE Band 5  1720  1845  GSM 1800; CDMA 1900; GSM Pulse 1900; H990 1900; DECT; LTE Band 1,3,4, 25; UMTS	020	960	820,				
1720   GSM   1800;   CDMA   1900;   GSM   Pulse   modulation   2   0.3   28   28   28   28   CT   CT   CT   CT   CT   CT   CT   C	930		CDMA				
1720 1845  GSM 1800; CDMA 1900; GSM 1900; GSM Pulse modulation 1970  1970  DECT; LTE Band 1,3,4, 25; UMTS			850,				
1720 1845  GSM 1800; CDMA 1900; GSM Pulse 1900; 1990 DECT; LTE Band 1,3,4, 25; UMTS  GSM Pulse 1900; TOMA 1900; TOMA 1900; TOMA 1900; TOMA 1900; TOMA 1800; TOMA 1900; TOMA 1900			LTE				
1845  1800; CDMA 1900; GSM Pulse 1970  1990  1990  1900; DECT; LTE Band 1,3,4,25; UMTS			Band 5				
CDMA 1900; GSM Pulse 1970 1990 1990 DECT; LTE Band 1,3,4, 25; UMTS	1720		GSM				
1900; GSM Pulse 1700- 1990 Pulse 1970 Pulse	1845		1800;				
1700- 1990   1990   1990; modulation 2 0.3 28   1970   1990   DECT; 217Hz   LTE   Band   1,3,4, 25; UMTS   UMTS			CDMA		2	0.3	28
1700- 1990 1990 DECT; 217Hz 21	1		-				
1970 1990 1900; modulation 2 0.3 28  DECT; 217Hz  LTE  Band  1,3,4, 25;  UMTS		1700-	GSM	Pulse			
1970 DECT; 217Hz LTE Band 1,3,4, 25; UMTS			1900;	modulation			
Band 1,3,4, 25; UMTS			DECT;	217Hz			
1,3,4, 25; UMTS			LTE				
UMTS			Band				
			1,3,4, 25;				
2450 2400- Bluetooth Pulse 2 0.3 28			UMTS				
2.00 2.00 2.00.00	2450	2400-	Bluetooth	Pulse	2	0.3	28

10 ENC Tables						
	2570	WLAN,	modulation			
		802.11	217Hz			
		b/g/n,				
		RFID				
		2450,				
		LTE				
		Band 7				
5240	5100-	WLAN	Pulse			
5500	5100- 5800	802.11	modulation	0.2	0.3	9
5785	5600	a/n	217Hz			



### WARNING

 Use of accessories and cables other than those specified or provided by the manufacturer of AirPex could result in increased electromagnetic emissions or decreased electromagnetic immunity of AirPex and result in improper operation.

#### Cable information:

Cable Name	Cable Length	Shielded or	Remark
	(m)	not	
Adapter	1.2	No	/
Cable			
Measuring	0.8	No	/
Cable			

#### 10 EMC Tables

 Use of AirPex adjacent to or stacked with other equipment should be avoided because it could result in improper operation. If such use is necessary, AirPex and the other equipment should be observed to verify that they are operating normally.

#### 11.Statement

#### Service Life

The service life of AirPex series products is 3 years.

#### Maintenance

MANUFACTURE will provide circuit diagrams, component part lists, descriptions, calibration instructions to assist to SERVICE PERSONNEL in parts repair.

### Disposal

The package should be recycled. Metal parts of the device are disposed as scrap metal. Synthetic materials, electrical components, and printed circuit boards are disposed as electrical scrap. The lithium batteries are disposed as special refuse. Please deal with them according to the local environmental protection laws and regulation.